

Lenovo IdeaPad Y550

Setup Poster v1.0



Read the safety notices and important tips in the included manuals before using your computer.

lenovo

ideapad

Unpack

Computer



Battery pack



AC adapter



Power cord



TV tuner adapter



(Specific models only)

Remote control



(Specific models only)

Manuals



- Setup Poster
- User Guide
- Other publications

- Some models may contain items that are not listed.
- If any item is missing or damaged, please contact your retailer.
- Everything for recovering factory-installed files and applications is on your hard disk eliminating the need for a recovery disc. For more information, see the included manuals.




P/N:148000845
Printed in China


Initial setup instructions

1 Install battery pack


Unlock both switches and insert the battery pack. After inserting the battery pack, make sure both switches are in the lock position.



2 Connect to the power




3 Turn on the Power



4 Configure the Operating System following the on-screen instructions

Slide your finger across the touch pad surface to move the cursor. Click the left button to select items.



Supplied softwares

VeriFace™

VeriFace is a face recognition software which takes a digital snapshot, extracts key features of your face, and creates a digital map that becomes the system's "password".

OneKey Rescue System

OneKey Rescue System is an easy-to-use system which includes several applications to help you detect and remove viruses, and recover Windows system and personal data.

You can press OneKey Rescue System button  to activate OneKey Rescue System when your PC is turned off. Within the program, you can upgrade the virus definition and use antivirus tools, repair system kernel files, restore your system partition to the original factory status or to a previously generated backup. You may also transfer critical data or documents to other storage devices. All these features make OneKey Rescue System an important utility to secure your data.

OneKey Theater

OneKey Theater enlarges the color and volume range of your computer and brings you visual and aural impact when enjoying movies.

EasyCapture

EasyCapture helps you take pictures and videos with the integrated camera on your computer.

Energy Management

Energy Management manages your computer's power supply. It makes your computer work effectively at low energy cost according to different modes.

Power2Go

Power2Go burns data, music, videos and photos onto CDs, DVDs.

Norton Internet Security

Norton Internet Security is the latest product launched by Symantec in 2008. It is customized against the latest threats to network safety that concern the user, and includes features like anti-virus, firewall, anti-spyware, privacy protection and anti-phishing.

Adobe Reader

Adobe Acrobat Reader enables you to view PDF files. With its snapshot tool and text selector, you can copy the content into various editing software programs.

ReadyComm

ReadyComm is a software for intelligent wireless connection configuration and safe, quick resource sharing.

Lenovo, lenovo logo, IdeaPad, VeriFace, OneKey Rescue (OneKey Recovery, OneKey AntiVirus), APS, Power Express, Energy Management, OneKey Theater and ReadyComm are either registered trademarks or trademarks of Lenovo in the United States and/or other countries.

© Copyright Lenovo 2008 All rights reserved.

Buttons and functions

Integrated camera

The integrated camera offers an improved notebook experience for video-centric applications.

OneKey Rescue System button / Power button


-  Repair Windows system kernel files or restore the system to its original state in case of an unrecoverable error.
-  Start the computer.


Fn key

 Used in combination with other keys to access special features.

Function key combinations +

 Turn on/off integrated camera.	 Enter sleep mode.
 Turn on/off the LCD screen.	 Shift to other connected display devices.
 Open the interface for display resolution settings.	 Open the interface for integrated wireless devices settings (enable/disable).
 Enable/disable touch pad.	 Switch between character or numeric input mode.
 Activate the pause function.	 Activate the break function.
 Enable/disable Scroll Lock.	 Turn on/off the insert input.
 Activate the system request.	

 Adjust the sound volume.

 Adjust the display brightness.

Touch inductive panel


-  Select and open preset applications.
-  Open the OneKey Theater.
 -  Open the Dolby function setup screen.

Volume buttons

-  Volume up
-  Volume down
-  Mute

Integrated wireless device switch

-  Use this switch to disable the wireless radio of all the wireless devices on your computer.



Attention: Differing in backlight, the LCD on marketing can be divided into CCFL (Cold Cathode Fluorescent Lamp) LCD and LED (Light Emitting Diode) LCD. The LCD applied LED backlight technology which adopts LED as the light source and is mercury-free and more energy-saving than CCFL backlight technology. (Please refer to the actual product)

* The illustrations in this manual may differ from the actual product. Please refer to the actual product.